


Removing Turn Signal Switch

Remove plastic
around steering
wheel
Unplug wiring



Push in
clip to
release
switch



Lift switch
up to
remove



DO NOT

remove steering wheel or clock spring.